



CUT, FOIL AND TIN. SOLDER BODY TOGETHER
FLIP PATTERN OVER FOR LEGS AND EARS



KEEP FLAT



BEND SLIGHTLY
FOR FOOT &
SOLDER.
REPEAT FOR OTHER SIDE

ANGLE LEG SLIGHTLY AND
SOLDER TO BACK OF LEG



solder on other back leg, arm and ears,
slightly bent outwards and solder



SOLDER ON ACORN AS PICTURED



SOLDER ON OPPOSITE ARM
AND ATTACH TO NUT.



VIEW FROM TOP



CARFULLY CLEAN, PATINA AND POLISH!

